
The Audio System is housed in a 4RU Gator Case (Mixer, Wireless Receiver & USB Interface).
Powered Speaker
Camera 1
Camera 2
Laptop
Projector
Wired Mic
Two Wireless Mics
USB
USB Hub
Second Monitor
Laptop case holds PC and second monitor. **Projector** has a case and holds HDMI cable. **Powered Speaker case** is small carry bag. **Projection screen** does not have a case.


USB Camera 1
2nd Monitor
USB Audio Interface RCA Connections
USB Hub
Zoom® PC
Projector
HDMI
USB Camera 2
Left Only
Anchor AN-130 Powered Speaker
The output of the mixer is 600 ohms /XLR and a "Y" cable splits the signal equally to the USB interface and the powered speaker.
Audio Technica AT-341A
Four Channel Audio Mixer
CH1
CH2
Ch3
Wired Mic
Sampson Two Channel Wireless Mic Receiver
SPECIAL NOTE: The Powered Speaker has two separate input cables (L&R RCA). The Anchor AN-130 has the required line level inputs, (a passive mix bus). A "Y" adapter cannot be used. If a powered speaker isn't available that has a mix capability, a passive mix could be constructed externally with a few connectors and resistors.