

Yaesu FT-991 Microphone EQ settings – These affect HF audio **ONLY**

(Press MENU/SETUP to access settings)

These are the settings I use with my HEIL PRO 7 headset with a Dynamic microphone

MENU #	SETTING
107	SSB OUT LEVEL 50
110	SSB TX BPF 300-2700
119	PRMTRC EQ1 FREQ 300
120	PRMTRC EQ1 LEVEL 5
121	PRMTRC EQ1 BWTH 10
122	PRMTRC EQ2 FREQ 900
123	PRMTRC EQ2 LEVEL -5
124	PRMTRC EQ2 BWTH 10
125	PRMTRC EQ3 FREQ 2000
126	PRMTRC EQ3 LEVEL 3
127	PRMTRC EQ3 BWTH 10
128	P-PRMTRC EQ1 FREQ 500
129	P-PRMTRC EQ1 LEVEL 0
130	P-PRMTRC EQ1 BWTH 2
131	P-PRMTRC EQ2 FREQ 1500
132	P-PRMTRC EQ2 LEVEL 0
133	P-PRMTRC EQ2 BWTH 1
134	P-PRMTRC EQ3 FREQ 2800
135	P-PRMTRC EQ3 LEVEL 7
136	P-PRMTRC EQ3 BWTH 1

MIC-EQ "ON"

PROC "ON" 40

(setting speech processor higher than 40 will result in distortion of your audio,
and is best with microphone 2 to 3 inches from your mouth)

MIC GAIN 50

NOTE : you may find the settings under different menu numbers due to different firmware

DISCLAIMER : Everyone's voice is different! What may work for me, may not work best for you. However, this is a good starting point.....